


「 Chapter 4 Ball Launcher 」



「 Ball Launcher Robot 」

► 00: Assembly Guide of Mainboard ELF



1x 328P MicroChip Module V1.0



1x WeeeMake Bluetooth 4.1 Module



1x Light Sensor (Pin)



1x IR Receiver (Pin)



1x Sound Sensor (Pin)



1x ELF Mainboard



1x ELF Mainboard Lid




1x ELF Mainboard Base



1x RGB LED - 8 (Pin)




2x DC/Encoder Motor Driver



「Ball Launcher Robot」

▶ 00: Assembly Guide of Mainboard ELF



「 Ball Launcher Robot 」

► 00: Assembly Guide of Mainboard ELF



4xScrew M4*8




2xLinkage 0208-24



1x Beam 1030-100-B



1x ELF Mainboard Assembly



「 Ball Launcher Robot 」

▶ 00: Assembly Guide of Mainboard ELF

Tips:

The default sensors on mainboard ELF is installed as follows:

Port 1 - Light Sensor

Port 2 - IR Receiver


Port 3 & 4 - DC/Encoder Motor Driver

Port 5 - Sound Sensor

MCU Port - 328P Micro Chip

Communication Port - Bluetooth Module


Special port - RGB LED -8 Module



「Ball Launcher Robot」


► 01: Assemble Base Structure

-  1x Beam 1030-100
-  1x Beam 1030-100-B
-  2x Beam 0410-186
-  8x Screw M4*8



► 02: Assemble Driven Wheel

-  4x 56T-Plastic Gear
-  2x Threaded shaft 4-48
-  4x Flange Copper Bearing
-  2x Shaft Collar - 4mm
-  4x Nut M4
-  2x Nylon Spacer 4*7*10
-  2x Headless Screw M4*3




Tips:
Please pay attention to the hole
position and direction.

「 Ball Launcher Robot 」


► 03: Assemble Active Wheel

-  2x56T-Plastic Gear
-  1xDriving Flange Hub 4mm
-  2xScrew M4*20



► 04: Assemble the Encoder DC Motor-25(188RPM)

-  2x Countersunk Head Screw M3*6
-  1x25 Motor Bracket
-  1x Encoder DC Motor-25 (188RPM)



Tips:
Please pay attention to the bracket direction and screw hole position.

「 Ball Launcher Robot 」


► 05 : Assemble Base Structure Motor



4x Screw M4*8



2x Encoder DC Motor-25 (188RPM)Assembly



► 06: Assembly and Fix The Active Wheel




2x56T-Plastic Gear Assembly



4x Nylon Spacer 4*7*3



2xHeadless Screw M4*5



「 Ball Launcher Robot」




► 07: Assemble Caterpillar Track



52xTrack



52xTrack Axle 2*26





Tips: Each track belt consists of 26 rubber tracks and 26 track axles.

► 07: Assemble Caterpillar Track



2xTrack Assembly




Tips: Pay attention to the correct direction.

「 Ball Launcher Robot 」


► 08: Assemble Beam 1030-132

-  1x Beam 0410-130
-  1x Beam 1030-132
-  2x Screw M4*10
-  2x Nut M4



► 08: Assemble Beam 1030-132

-  1x Beam 1030-132 Assembly
-  1x Beam 1030-132
-  4x Screw M4*8




「 Ball Launcher Robot 」

► 09: Assemble Beam 0410-154

 1x Beam 0410-154

 2x Screw M4*10

 2x Nut M4



「 Ball Launcher Robot 」

► 10: Assemble the DC Motor-25




1x25 Motor Bracket



1xDC Motor-25 (50RPM)



2xCountersunk Screw M3x6



Tips: Please pay attention to the bracket direction and screw hole position

► 11: Assemble Beam 0410-130




1xDC Motor-25 (50RPM) Assembly



1x Beam 0410-130




2x Screw M4*8



「Ball Launcher Robot」

► 12: Assemble Beam 0410-106


-  1xBeam 0410-106
-  1xDriving Flange Hub 4mm
-  2xScrew M4*8



Tips: Please pay attention to the hole position and direction.

► 13: Assemble Beam 0410-106 on DC Motor-25

-  2xNylon Spacer 4*7*2
-  1xHeadless Screw M4*5



Tips: Please screw the headless screw M4*5 to the flat surface of motor shaft.

「Ball Launcher Robot」


► 14: Assemble Beam1030-68



1x Beam 1030-68



2x Screw M4*8



► 15: Assemble Flat Shaft 4-160



4x Nylon Spacer 4*7*2



2x Nylon Spacer 4*7*3



2x Shaft Collar - 4mm



2x Flange Copper Bearing

Nylon Spacer 4*7*2


Nylon Spacer 4*7*3



1x Flat Shaft 4-160



2x Headless Screw M4*3




Tips: When installing the Flat Shaft 4-160 symmetrically, pay attention to lock the Headless Screw M4*3 appropriately to ensure flexible rotation of the structure.

「Ball Launcher Robot」

► 16: Assemble the 18650 Lithium Battery


-  2x18650 Lithium Battery
-  1x18650 Battery Holder Cover
-  1x18650 Battery Holder
-  2xScrew M4*8
-  2xScrew Nut M4



Reference view

► 17: Assemble Slide Beam 0824



-  1xSlide Beam 0824-32
-  1xSlide Beam 0824-80
-  1xSlide Beam 0824-96
-  4xScrew M4*14



「Ball Launcher Robot」


► 17: Assemble the Linear Motion Slide Unit A

-  1x Linear Motion Block 32x40
-  1x Linkage 0208-56
-  4xBearing MR74z
-  4xWheel 5.5*7*9
-  2xScrew M4*25
-  2xScrew M4*30
-  4xNylon Lock Nut M4
-  8xAluminum Column 4*6*6



Tip: Pay attention to the hole position and direction of slide unit, neither be too tight to stuck sliding, nor too loose to shake on beam.

► 18. Assemble the Linear




Tips: Please pay attention to the hole position and direction.

「Ball Launcher Robot」


► 18: Assemble Beam 0410

-  1xBeam 0410-106
-  2xBeam 0410-154
-  2xScrew M4*25
-  2xNylon Lock Nut M4



► 19: Assemble Beam

-  2xBeam 0824-16-A
-  2xScrew M4*20
-  4xScrew M4*25
-  6xNut M4
-  4xNylon Spacer 4*7*2
-  2xBeam 0410-130



「 Ball Launcher Robot 」


► 20: Assemble Bracket 3x3



1xBracket 3x3



2xScrew M4*8




► 21: Assemble Screw M4*8



1x Screw M4*8



1xNylon Lock Nut M4



Tips: Install the screws and nuts according to the hole positions and directions as shown in the figure. Do not tighten the locknut too tightly.

「 Ball Launcher Robot 」

► 22: Assemble Screw M4*25




1xLinkage 0208-24



2xScrew M4*25




2xNut M4



► 23: Assemble Rubber Band 2*60



4x Rubber Band 2*60



Tips: Rubber bands numbers could be adjusted subject to actual situation.

「 Ball Launcher Robot 」


▶ 24: Assemble Slide Beam 0824-32



2xSlide Beam 0824-32




2xScrew M4*14



▶ 25: Fix Slide Beam 0824-32




2xScrew M4*14




「 Ball Launcher Robot 」

► 26: Assembly Launch Structure to the Moving Platform



► 27: Assemble MG995 Servo

- 1xMG995 Servo
- 1x56T-Plastic Gear
- 1xMG995 Servo Aluminum Alloy Hole Arm
- 1x Cross Head Screws M3*5
- 1xMG995 Bracket
- 4xScrew M4*6




Tips:Please pay attention to the hole position and direction.

「 Ball Launcher Robot 」

► 27: Assemble MG995 Servo

2xScrew M4*10

2xNut M4



► 28: Assemble Beam 0410-106

1x Beam 0410-106

1x Screw M4*35


1x Screw M4*25

2xNylon Lock Nut M4

2xNylon Spacer 4*7*2

1xNylon Spacer 4*7*3

1xNylon Spacer 4*7*10



Tips: Be careful not to tighten the screws too much, the gear needs to be able to rotate.

「Ball Launcher Robot」

► 29: Assemble RJ11 Adapter V1.0 Module




1x RJ11 Adapter V1.0 Module



2x Screw M4*8



2xNut M4




► 30: 31.Assemble the Mainboard ELF



1xELF Mainboard Assembly



2xScrew M4*8




「Ball Launcher Robot」

▶ 31: Wiring

-  1x Power cord 5.5-2.1
-  1x DC Motor Wire-35cm
-  1xRJ11 Cable-20cm

18650 Lithium Battery Holder
→ Power cord 5.5-2.1
→ Power supply port

Port D → RJ11 Cable-35cm → RJ11 Adapter V1.0 Module




▶ 31: Wiring


-  2x Encoder Motor Wire-25cm

Encoder DC Motor-25 (188RPM)
A → Encoder Motor Wire-25cm →
ELF mainboard port 3

Encoder DC Motor-25 (188RPM) B →
Encoder Motor Wire-25cm →
ELF mainboard port 4



「Wiring」



「Completion Diagram」

